

## ENGINE SERIAL NUMBER GUIDE

Models	(Serial number of first engine built in year)						
	1971	1972	1973	1974	1975	1976	1977
2-71 (2A)	81549	85087	86279	88906	92258	96031	98179
3-71 (3A)	78614	79536	80506	81772	83322	85360	86622
4-71 (4A)	169890	175996	182907	192267	201395	211904	217942
6-71 (6A)	232307	248936	272037	295884	317658	332518	346750
12-71 (12A)	7443	7599	—	—	—	—	—
24-71 (24A)	566	568	—	—	—	—	—
2-53 (2D)	29699	31648	—	—	—	—	—
3-53 (3D)	78232	92337	103048	114363	126016	132996	140042
4-53 (4D)	74784	81979	91891	104147	118187	130979	142705
6V-53 (6D)	75849	84457	93545	104554	117870	137232	150301
8V-53 (8D)	4508	5056	5779	6508	—	—	6757
8.2 (8G)	—	—	—	—	—	—	—
12V-149 (12E)	1128	1511	1797	2441	3308	4136	4516
16V-149 (16E)	077	258	406	2258	2715	3388	3784
6V-71 (6VA)	59501	63698	68936	76103	83893	90735	96214
8V-71 (8VA)	133386	164953	212755	263580	312998	332778	352434
12V-71 (12VA)	24195	27217	31036	35732	42694	47948	51768
16V-71 (16VA)	6256	7091	7696	8793	10414	12225	13472
6V-92 (6VF)	—	—	—	330	753	1163	7597
8V-92 (8VF)	—	—	—	608	3000	4398	8331
12V-92 (12VF)	—	—	—	—	—	—	—
16V-92 (16VF)	—	—	—	—	1014	1149	1360
3-53 (DB)**	—	—	—	—	—	—	—
4-53 (DB)**	—	—	—	—	—	—	6103
6V-53 (DB)**	—	—	—	—	—	—	—
6V-71†† (6VW)	—	—	—	—	—	—	—
8V-71†† (8VW)	—	—	—	—	—	—	—

\*\*53 Brazil engines

††V-71 Vauxhall engines

BDC

BDC for Manuals - specs - Bolt torques

<https://barringtondieselclub.co.za/>

## ENGINE SERIAL NUMBER GUIDE

Models		(Serial number of first engine built in year)					
		1978	1979	1980	1981	1982	1983
2-71	(2A)	99832	102060	103084	104064	105345	10593B
3-71	(3A)	88356	91254	93850	96585	98903	99743
4-71	(4A)	226719	235791	244142	252368	260660	265225
6-71	(6A)	363474	383376	402393	414833	426666	431867
12-71	(12A)	—	—	—	—	—	—
24-71	(24A)	—	—	—	—	—	—
2-53	(2D)	—	—	—	—	—	—
3-53	(3D)	149459	156459	165142	173980	183686	187591
4-53	(4D)	153389	163134	173284	185204	197307	201552
6V-53	(6D)	164924	177379	189278	203804	213393	220648
8V-53	(8D)	6779	—	—	—	—	—
8.2	(8G)	—	870	2380	26314	49621	67726
12V-149	(12E)	5118	5542	5902	6337	7807	8097
16V-159	(16E)	4325	5072	5546	6255	7070	7506
6V-71	(6VA)	102397	109395	114948	121419	127934	130333
8V-71	(8VA)	370909	387198	403649	414883	424827	429985
12V-71	(12VA)	56934	62224	66325	70811	75323	76898
16V-71	(16VA)	15078	16154	16815	17665	18647	18997
6V-92	(6VF)	21033	39536	59288	75269	87940	98800
8V-92	(8VF)	18770	34236	56967	66994	75197	81446
12V-92	(12VF)	—	603	605	690	1079	1358
16V-92	(16VF)	2033	2773	3470	4517	5698	6060
3-53	(DB)**	1631	4238	5326†	—	—	—
4-53	(DB)**	30611	45568	53632†	—	—	—
6V-53	(DB)**	1501	6057	7186†	—	—	—
6V-71	(6VW)††	740	951	1160	1691	—	—
8V-71	(8VW)††	3496	4605	5302	6023	—	—

\*\*53 Brazil engines

† Last unit built

††V-71 Vauxhall engines

**BDC**

BDC for Manuals - specs - Bolt torques

<https://barringtondieselclub.co.za/>

## ENGINE SERIAL NUMBER GUIDE

Models		(Serial number of first engine built in year)			
		1984	1985	1986	1987
2-71	(2A)	106014	106114	106233	106305
3-71	(3A)	100419	101029	101386	101649
4-71	(4A)	268457	273305	277157	278921
6-71	(6A)	437367	444805	450007	454231
3-53	(3D)	192100	198002	201788	204163
4-53	(4D)	206188	211860	215845	218846
6V-53	(6D)	226970	232563	237118	240091
8.2L	(8G)	90548	116572	145645	169919
8V-149	(8E)			2533	2554
12V-149	(12E)	8193	8596	8761	8878
16V-149	(16E)	7780	8288	8555	8800
6V-71	(6VA)	132764	134457	136777	138249
8V-71	(8VA)	433763	438112	441455	444781
12V-71	(12VA)	77992	79193	80439	81348
16V-71	(16VA)	19254	19438	19555	19691
6V-92	(6VF)	110203	124769	138252	147899
8V-92	(8VF)	87677	99597	109240	116454
12V-92	(12VF)	1579	1854	2095	2418
16V-92	(16VF)	6184	6521	6728	6942

BDC

BDC for Manuals - specs - Bolt torques

<https://barringtondieselclub.co.za/>